



### WATER ANALYSER /-SENSOR

#### ***Dimensions***

Length(mm).....: 180                                 Width(mm).....: 270                                 Height(mm).....: 100  
Weight (kg).....: 2

#### ***Construction year***

Built.....: 2007

#### ***Type***

Item type.....: Measure water content in oil  
Fabricator.....: Pall  
Model.....: WS-04  
                          WSPC06  
Serial no.....: Pall WS-04: Ser. No: 1889  
                          Pall WSPC06 Ser. No: 4490

#### ***Power supply***

Battery.....: 9V Battery

#### ***Content***

Content.....: 1 ea. Pall WS-04  
                          1 ea. Pall WSPC06  
                          1 ea. Extra battery  
                          1 ea. 1/4" NPT fitting

#### ***Flow / Pressure / Volume***

Measure Range.....: 0-100% saturation / ppm

#### ***Additional information***

Equipment / Functions.....: Measure water content in oil. (Petroleum and synthetic fluids and fuels)

To read out results in ppm you need to program the unit with an equation for the specific oil. Must be specified in Order